

NVIDIA TAO 数据转换

GUPAO TECH

把coco数据集按TAO的要求用起来

我们的愿景

推动每一次人才升级

我们的使命

让每个人的职业生涯不留遗憾

请在此处
输入文字

请在此处
插入二维码

进入TAO环境

conda env list

进入tao运行环境


conda activate launcher

进入 cv_samples_v1.4.0目录

cd ~/cv_samples_v1.4.0

启动jupyter

jupyter notebook --ip 0.0.0.0 --port 8888 --allow-root



Object Detection using TAO YOLOv4 Tiny

Transfer learning is the process of transferring learned features from one application to another. It is a commonly used training technique where you use a model trained on one task and re-train to use it on a different task.

Train Adapt Optimize (TAO) Toolkit is a simple and easy-to-use Python based AI toolkit for taking purpose-built AI models and customizing them with users' own data.

The diagram illustrates the TAO Toolkit architecture. It is divided into two main sections: VISION AI and CONVERSATIONAL AI. The VISION AI section shows a flow from Pre-trained models (NGC) and Custom Dataset (Jupyter Notebooks) into the TAO Toolkit. The TAO Toolkit is composed of TAO UI*, TAO TOOLKIT**, and Jupyter Notebooks. The TAO TOOLKIT** section includes Data Prep & Augmentation, Train, and Prune. The TAO Toolkit is supported by CUDA-X, which includes NVIDIA Containers RT, CUDA, cuDNN, and TensorRT. The TAO Toolkit is also supported by TRAINING PLATFORMS (Workstation, DGX, Cloud) and INFERENCE PLATFORMS (Jetson, T4, Ampere).

Learning Objectives

In this notebook, you will learn how to leverage the simplicity and convenience of TAO to:

- Take a pretrained model and train a YOLO v4 Tiny model on the KITTI dataset
- Prune the trained YOLO v4 Tiny model

TAO 目录规划

LOCAL_PROJECT_DIR=~/.cv_samples_v1.4.0

LOCAL_DATA_DIR=~/.cv_samples_v1.4.0/data

LOCAL_EXPERIMENT_DIR=~/.cv_samples_v1.4.0/yolo_v4_tiny

容器目录对应

DATA_DOWNLOAD_DIR=/workspace/tao-experiments/data


USER_EXPERIMENT_DIR=/workspace/tao-experiments/yolo_v4_tiny

SPECS_DIR=/workspace/tao-experiments/yolo_v4_tiny/specs

TAO KEY

<https://ngc.nvidia.com/signin>

账号密码登陆
查看 KEY



TAO 格式转换

```
tao yolo_v4_tiny dataset_convert [-h] -d <dataset_spec>  
-o <output_tfrecords_file>  
[--gpu_index <gpu_index>]
```

实例：

```
tao yolo_v4_tiny dataset_convert -d /workspace/tao-experiments/data/
```


dataset_spec配置文件

coco_config

Here are descriptions of the configurable parameters for the `coco_config` field:

Parameter	Datatype	Default	Description	Supported Values
<code>root_directory_path</code>	string	-	The path to the dataset root directory	-
<code>image_dir_names</code>	string (repeated)	-	The relative path to the directory containing images from the path in <code>root_directory_path</code> for each partition.	-
<code>annotation_files</code>	string (repeated)	-	The relative path to the directory containing JSON file from the path in <code>root_directory_path</code> for each partition.	-
<code>num_partitions</code>	int	2	The number of partitions in the data. The number of partition must match the length of the list for <code>image_dir_names</code> and <code>annotation_files</code> . By default, two partitions are generated: <code>val</code> and <code>train</code> .	$n = \text{len}(\text{annotation_files})$
<code>num_shards</code>	int (repeated)	[10]	The number of shards per partitions. If only one value is provided, same number of shards is applied in all partitions	

TAO格式转换配置文件 dataset_spec

实例: spec-train.txt

```
coco_config {  
  root_directory_path: "/workspace/tao-  
experiments/data/pingpang.v2i.coco/"  
  img_dir_names: ["train"]  
  annotation_files: ["train/_annotations.coco.json"]  
  num_partitions: 1  
  num_shards: [10]  
}  
image_directory_path: "/workspace/tao-  
experiments/data/pingpang.v2i.coco/train"
```

验证数据格式转换 配置文件 spec-val.txt

```
coco_config {  
  root_directory_path: "/workspace/tao-  
experiments/data/pingpang.v2i.coco/"  
  img_dir_names: ["valid"]  
  annotation_files: ["valid/_annotations.coco.json"]  
  num_partitions: 1  
  num_shards: [2]  
}
```

```
image_directory_path: "/workspace/tao-  
experiments/data/pingpang.v2i.coco/valid"
```

TAO 验证数据集 coco格式转换tfrecord

```
tao yolo_v4_tiny dataset_convert [-h] -d dataset_spec>  
-o <output_tfrecords_file> [--gpu_index <gpu_index>]
```

```
tao yolo_v4_tiny dataset_convert -d /workspace/tao-  
experiments/data/spec-val.txt -o /workspace/tao-  
experiments/data/val/tfrecords/val --gpu_index 0
```

使用TAO

进入jupyter 按照案例来

谢谢观赏

GUPAO TECH



替换小标题文字，或简要说明

我们的愿景

推动每一次人才升级

我们的使命

让每个人的职业生涯不留遗憾

请在此处
输入文字

请在此处
插入二维码